






Bedienungsanleitung Traktoren 67XX Serie / Operating instructions
for 67XX Series tractors / Mode d'emploi Tracteurs série 67XX /
Instrucciones de uso tractores serie 67XX / Gebruikshandleiding
tractoren serie 67XX

A Batterien einlegen / Inserting the batteries / Placer les piles / Colocación de las pilas / Baterijen plaatsen




1



2



3



B Systemstart / System start / Démarrage du système / Inicio del sistema / Systeem starten




1 Download SIKUCONTROL32APP:




1.




2.




2



3




4




**C Systemstart / System start / Démarrage du système /
Inicio del sistema / Systeem starten**




1




2




3




4



D Steuerung / Control / Commande / Control / Besturing




oder / or / ou / o / of




E Licht / Lights / Lumière / Luces / Verlichting

1



2



3



Mode 1




Mode 1



Mode 2



Mode 2



4



OFF



OFF




OFF



OFF




OFF




F Blinken / Flashing / Clignotement / Intermitentes / Knipperen

1



2




3



+






G automatisch Kuppeln / Automatic coupling / Attelage automatique / Acoplamiento automático / Automatisch koppelen


1


1.




2

2.









H Frontlader heben und senken / Raising and lowering front loader / Lever et abaisser le chargeur frontal / Subir y bajar el cargador frontal / Frontloader omhoog en omlaag

1




2




I Schaafel heben und senken / Raising and lowering shovel / Lever et abaisser la pelle / Subir y bajar la pala / Schuif omhoog en omlaag




1





2




J Anbaugeräte montieren / Mounting front loader accessories / Monter des accessoires pour chargeur frontal / Montar implementos / Aanbouwapparaten monteren




oder / or / ou / o / of



Set 3661




Set 7070




K Palette aufladen und Parallelführung der Gabel / Loading a pallet and parallel motion of the fork / Charger une palette et guidage parallèle des fourches / Cargar paleta y guiado paralelo de la horquilla / Paletvork laden en parallelgeleiding van de vorken


1




2



3



4




L Lenkjustierung / Steering adjustment / Ajustage de la direction / Ajuste de dirección / Stuurinrichting afstellen


1




2



3



1.



2.



Set Center




→ <http://www.siku.de/de/downloads.html>

M Eigenen Modellnamen vergeben / Assign your own model name / Attribuer des noms de modèles propres / Asignar un nombre de modelo propio / Eigen modelnaam geven

1



2



3

